

FR

DE

EN

NL

IT

ES

PL


RU

CS


HU

TR

# JA39 - JA40 - JA41



A



B

2x

C003666-B



Notice de montage

Français

## **Kit de conversion propane**

Montageanleitung

Deutsch

## **Umbausatz auf Propan**

Assembly Instructions

English

## **Propane conversion kit**

Montage-instructie

Nederlands

## **Propaan-ombouwkkit**

Istruzioni di montaggio

Italiano

## **Kit di conversione a gas propano**

Návod k montáži

Česky

## **Přestavbová sada na propan**

Instrucciones de montaje

Español

## **Kit de conversión propano**

Összeszerelési útmutató

Magyar

## **Propán átállító készlet**

Instrukcja montażu

Polski

## **Zestaw do przestawienia na propan**

Montaj kılavuzu




Türkçe

## **Propan dönüşüm kiti**







Инструкция по монтажу

РУССКИЙ



## **Набор для переоборудования на пропан**



M002543-A



C003664-D



C003676-A

Procéder au réglage du rapport air / gaz.

- Se reporter à la notice d'installation et d'entretien de la chaudière

Dann das Luft/Gas-Verhältnis einstellen.

- Siehe Installations- und Wartungsanleitung des Heizkessels

Set the air/gas ratio.

- Refer to the installation and maintenance instructions of the boiler

Controleer de instelling van de gas-/luchtverhouding.

- Zie de installatie- en onderhoudshandleiding van de ketel

Potom nastavít poměr vzduch/plyn.

- Viz návod k instalaci a údržbě kotle

Hava/gaz oranını ayarlayınız.

- Kazan kurulum ve bakım notlarına bakınız

Procedere con la regolazione del rapporto aria/gas.

- Fare riferimento alle istruzioni di installazione e di manutenzione della caldaia

Ajustar la relación aire/gas.

- Consultar las instrucciones de instalación y mantenimiento de la caldera

Ustawić stosunek powietrze-gaz.





- Patrz instrukcja instalowania i konserwacji kotła

Приступить к настройке соотношения воздух / газ.

- См. инструкцию по установке и техническому обслуживанию котла

Végezze el a levegő-gáz arány beállítását.

- A kazán telepítési és karbantartási kézikönyve szerint



22/10/2015



300026926-001-03

AD051-AC